



# Nikon Coolpix S4100 LCD Screen Replacement

In this guide, you will find instructions on how to replace the LCD screen for your camera.

Written By: Matthew Willis



## INTRODUCTION

If your screen breaks or is no longer responsive to touch, then you will need to replace it. The LCD screen itself has two wires attached that will need to be separated from the motherboard, and reinstalled with the new part.

---

### TOOLS:

- [Precision tweezers](#) (1)
  - [Phillips #000 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
  - [Spudger](#) (1)
-

## Step 1 — External Casing



- Using a Philips #000 head screwdriver, remove the 8 screws (3.30 mm) visible on the external part of the camera.
- There are 2 on each side, and 4 on the bottom.

## Step 2




- Remove the black casing on the back of the camera that runs around the LCD screen.

## Step 3




- Using the Philips #000 head screwdriver, remove the 1.90 mm internal screw located just above the lanyard mount.


## Step 4



- Pry off the front shell casing.

 If you find this difficult, use a prying tool to help gently remove the casing.

## Step 5



- Using the Philips #000 head screwdriver, remove the 3.30 mm screw located on the side of the camera near the lanyard mount.

## Step 6




- Using the Philips #000 head screwdriver, remove 2 additional 3.30 mm screws holding the lanyard mount in place.

## Step 7



- Remove the lanyard mount and accompanying side shell casing off of the camera.

## Step 8



- Using the Philips #000 head screwdriver, remove the 3.30 mm screw securing the top shell casing.



## Step 9




- Using the Philips #000 head screwdriver, remove the 3.40 mm screw located on the front of the camera in the upper corner by the LED light.

## Step 10




- Remove the remaining side shell casing.

## Step 11



- Remove the top shell casing.


## Step 12 — Functional Button Plate



- Using the Philips #000 head screwdriver, remove the 3.40 mm screw located near the functional buttons.



## Step 13





- Using precision tweezers, remove the ribbon cable that runs from the functional buttons plate to the under side of the motherboard.

## Step 14




- Using precision tweezers, lift up the bottom of the functional buttons plate and remove the metal plate.

## Step 15 — LCD Screen




- Using precision tweezers, gently remove the ribbon cable running from LCD to the bottom side of the motherboard.

## Step 16



- Using precision tweezers, gently lift up on the black strip of the ZIF Connector securing the cable from the LCD to the motherboard.
  - Then, gently remove the wire by pulling the base of the ribbon cable towards the LCD screen.
- ⚠ Do not poke or destroy the cable itself. Be careful to only grab the black fold in the tweezers.
- ℹ The black strip will fold back to reveal the cable, but remain attached to the motherboard.

## Step 17



- Remove the LCD screen from the metal mount.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 08:30:33 AM.